



What's in the box:

- Sprint R850 Mobile Hotspot
- Power Adapter

How to connect your Chromebook to the Sprint Mobile Hotspot:

- Remove the hotspot and power adapter from the box
- Connect the power adapter to the hotspot and plug the power adapter into an outlet
- Press the power button on the hotspot until "Welcome" appears on the screen
- Allow time for the hotspot to connect
- "Sprint" will appear on screen when device has connected
- On your Chromebook, click on the 🐬 wireless icon at the bottom right of your screen
- Click on the arrow beside of "No Network" or the Wi-Fi name that is displayed
- On your hotspot press the power button once and the WiFi Name will show on the screen
- Scroll down on the list that appears on your Chromebook until you find the one that matches
- Click on the WiFi name that matches your hotspot
- On your hotspot press the power button twice and the WiFi Password will show on the screen
- Enter this WiFi Password on your Chromebook when prompted
- Your Chromebook should now be connected to your hotspot